Week 4 Homework Submission File: Linux Systems Administration

Step 1: Ensure/Double Check Permissions on Sensitive Files

- 1. Permissions on '/etc/shadow' should allow only 'root' read and write access.
 - Command to inspect permissions: Is -I /etc/shadow
 - Command to set permissions (if needed):
- 2. Permissions on '/etc/gshadow' should allow only 'root' read and write access.
 - Command to inspect permissions: Is -I /etc/gshadow
 - Command to set permissions (if needed):
- 3. Permissions on `/etc/group` should allow `root` read and write access, and allow everyone else read access only.
 - Command to inspect permissions: Is -I /etc/group
 - Command to set permissions (if needed):
- 4. Permissions on `/etc/passwd` should allow `root` read and write access, and allow everyone else read access only.
 - Command to inspect permissions: Is -I /etc/passwd
 - Command to set permissions (if needed):

Step 2: Create User Accounts

- 1. Add user accounts for `sam`, `joe`, `amy`, `sara`, and `admin`.
 - Command to add each user account (include all five users):

sudo adduser sam

sudo adduser joe

sudo adduser amy

sudo adduser sara

sudo adduser admin

- 2. Ensure that only the `admin` has general sudo access.
 - Command to add 'admin' to the 'sudo' group: sudo usermod -aG sudo admin

Step 3: Create User Group and Collaborative Folder

1. Add an 'engineers' group to the system.


- Command to add group: sudo addgroup engineers
- 2. Add users 'sam', 'joe', 'amy', and 'sara' to the managed group.
 - Command to add users to 'engineers' group (include all four users):


sudo usermod -aG engineers sam sudo usermod -aG engineers joe sudo usermod -aG engineers amy sudo usermod -aG engineers sara


- 3. Create a shared folder for this group at 'home/engineers'.
 - Command to create the shared folder: sudo mkdir /home/engineers
- 4. Change ownership on the new engineers' shared folder to the 'engineers' group.
- Command to change ownership of engineer's shared folder to engineer group: sudo chown :engineers engineers


Step 4: Lynis Auditing

- 1. Command to install Lynis: sudo apt-get install -y lynis
- 2. Command to see documentation and instructions: sudo lynis --help
- 3. Command to run an audit: sudo lynis audit system
- 4. Provide a report from the Lynis output on what can be done to harden the system.
 - Screenshot of report output:









Bonus

- 1. Command to install chkrootkit: sudo apt-get install -y chkrootkit
- 2. Command to see documentation and instructions: chkrootkit --help
- 3. Command to run expert mode: sudo chkrootkit -x
- 4. Provide a report from the chkrootkit output on what can be done to harden the system.
 - Screenshot of end of sample output:

© 2020 Trilogy Education Services, a 2U, Inc. brand. All Rights Reserved.